

EXTECH® User Manual

Humidity / Temperature Pen Model 44550



Introduction

Congratulations on your purchase of this Humidity/Temperature Pen. Proper use and care of this meter will provide years of reliable service.

Instructions

- **ON/OFF Key**
Press the ON/OFF key to turn the Pen On or Off.
- **C/F Key**
Press the C/F Key to select the temperature units.
- **MAX/MIN Key**
Press the MAX/MIN key once to view the highest temperature and relative humidity readings. An up arrow ▲ will appear on the left side of the display to indicate that the MAX mode is active.
Press the MAX/MIN key a second time to view the lowest temperature and humidity readings. A down arrow ▼ will appear on the left side of the display to indicate that the unit is in the MIN mode.
Press the MAX/MIN key a third time to exit the MAX/MIN mode and return to normal operation
- **CLEAR Key**
With the down or the up arrow visible on the display (indicating that the Pen is in the MAX/MIN mode), press the CLEAR key to erase the stored MAX/MIN temperature and relative humidity readings. When the readings have been erased the display will indicate all dashes (- - -). New MAX/MIN readings will start recording within 3 seconds of the Clear function.-
+

Battery Replacement

1. Using a coin or a screwdriver, open the circular battery compartment on the rear of the pen by turning it in the direction of the OPEN arrow.
2. Replace the LR-44 battery and close the battery compartment.

Specifications

RH	20 to 90%	±5%
Temperature	-10 to 50°C	±1°C
	14 to 122°F	±2°F

Copyright © 2021 Teledyne FLIR LLC

All rights reserved including the right of reproduction in whole or in part in any form

www.extech.com