


EXTECH[®]

Big Digit Indoor/Outdoor Thermometer MODEL 401014



Operation

- 1) Open the battery compartment by pushing the cover on the rear of the instrument downward as indicated by the arrow. Remove the battery safety strip and the protective cover on the LCD display. The instrument is now ready for use.
- 2) The temperature units can be selected via the switch located on the rear of the instrument.
- 3) The upper display indicates the indoor temperature in degrees C or F. The lower display indicates the outdoor temperature in degrees C or F.
- 4) Displaying the minimum and maximum values.
 - a. Press the MAX/MIN button. The highest value measured since the Reset button was last pressed appears on the display.
 - b. Press the MAX/MIN button again to display the lowest value measured since the Reset button was last pressed.
 - c. Press the MAX/MIN button again to return to normal display operation.
- 5) Resetting (clearing) the MAX/MIN memory.
 - a) Press and hold the RESET button for 1 second while in the MAX/MIN display mode to clear the memory and start recording new max/min values.
- 6) The low battery flag will appear on the display when the battery voltage is low. Replace the battery when this occurs. To replace the battery open the battery compartment by sliding the battery cover on the rear of the instrument downward as indicated by the arrow. Replace the 1.5V 'AA' battery and replace the cover.

Never dispose of used batteries or rechargeable batteries in household waste.

As consumers, users are legally required to take used batteries to appropriate collection sites, the retail store where the batteries were purchased, or wherever batteries are sold.



Disposal: Do not dispose of this instrument in household waste. The user is obligated to take end-of-life devices to a designated collection point for the disposal of electrical and electronic equipment

Specifications	
Range	Indoor: 14.0 to 140.0°F (-10.0 to 60.0°C) Outdoor: -58.0 to 158.0°F (-50.0 to 70.0°C)
Accuracy	±1.8°F/1°C from 32 to 122°F (0 to 50°C) ±3.6°F/ 2°C from -58 to 32°F(-50 to 0°C) and 122 to 158°F (50 to 70°C)
Battery	One (1) 'AAA' 1.5 V battery
Cable	Outdoor temperature sensor cable length: Approx. 9' (3m)
Dimensions	3.9x4.25x0.75" (99x108x19mm)

Copyright © 2021 Teledyne FLIR LLC

All rights reserved including the right of reproduction in whole or in part in any form

www.extech.com